





marantz®

CD Receiver M-CR610


Quick Setup Guide

Start Here
Starten Sie hier
Commencez ici
Iniziare qui
Iniciar aquí
Start Hier
Starta här
Начните здесь
Zaczniij tutaj



Before you begin


What's In The Box



M-CR610



Power cord




Remote and batteries



Product manual
on CD-ROM



AM loop antenna




DAB/FM indoor
antenna

Required For Setup



Network router




Speakers



Speaker cables

Optional



iOS device and
USB cable




Router with WPS




Network cable

* For detailed instructions or assistance, please refer to the enclosed CD-ROM manual or visit our support site: www.marantz.com





1. Connection


1 Connect the left and right speakers to the M-CR610



R




L



2 Connect the power cord from the M-CR610 to a power outlet

3 Insert the batteries into the remote



Note: Please refer to the CD-ROM manual for Speaker A/B and Bi-amp connection options.

2. Connecting to your home network

Choose from one of the following options

Wireless

iOS device + USB cable

1 Power on **2** Select language **3** Make sure your iOS device is already connected to your WiFi Network then connect your iOS device to the front using your USB cable. Note: You must be running iOS version 5 or later

No WPS router

1 Power on **2** Select language **3** Auto scan
Please wait as your M-CR610 looks for available networks...

WPS router

1 Power on **2** Select language **3** Press the WPS button on your router

Wired

1 Connect a network cable between your M-CR610 and your router (cable not included) **2** Power on

4 Press the red Wi-Fi CONNECT Button on the back of your M-CR610

5 This message will appear on your iOS device. Select "Allow"

Connected!

4 Select your network name. If your network name is not listed, select "Rescan"

5 Enter your network password using the number keys on the remote control

Connected!

4 Within 2 minutes, Press and Hold the red Wi-Fi CONNECT button on the back of your M-CR610 for 3 seconds

5 Please wait as completing the connection can take a few minutes. The front panel of the M-CR610 will show the status of the connection


Connected!

3 Select language


4 Please wait while your M-CR610 connects to your wired network.

Connected!

Network Control



Select Network Control ON to control M-CR610 from your smartphone, use Apple AirPlay® and maintain constant network access. Power Consumption during standby power will be slightly higher.




Select Network Control OFF to reduce power consumption during standby. You can not turn on your M-CR610 from your smartphone or use Apple AirPlay until your M-CR610 is powered on manually and connects to your network.

Setup Complete!



3. Enjoying your music!

Enjoying Internet radio

- 1 Press the “INTERNET RADIO” button on the remote




- 2 Select a station




Enjoying music using Apple AirPlay


- 1 Tap the AirPlay Icon from within any app that supports AirPlay



- 2 Select the “Marantz M-CR610” from the AirPlay Device list



Note: Make sure your iOS device is on the same network as the M-CR610



Polski Русский Svenska Nederlands Español Italiano Française Deutsch **English**

Download the Marantz Remote App

Scan the QR code to download and install the Marantz Remote App using your smartphone and a scanning app or manually search the Apple App store or Google Play store for the “Marantz Remote App”

