

· · · · · · · · ·

## marantz

Super Audio CD Player **SA8005** 

Getting Started Mise en route Antes de empezar

### Welcome

Thank you for choosing a Marantz CD player. This guide provides step-by-step instructions for setting up your CD player.

### If you have setup problems:

If you need additional help in solving problems, contact Marantz customer service in your area.

For details, see the Marantz homepage. www.marantz.com

#### 1-855-ONE-MARANTZ

1-855-663-6272

Call for Assistance: 9:00AM to 8:00PM M-F E.S.T.


For frequency asked questions please visit

http://marantz.custhelp.com/app/answers/list

For US and Canada only

## **Before You Begin**

#### What's In the Box




## Setup


### There are six steps to the setup process.

- 1 Install batteries in the remote control unit
- 2 Connect the CD player to the amplifier
- 3 Plug the power cord into a power outlet
- 4 Turn the CD player's power on
- 5 Begin music playback
  - ► Play a CD or Super Audio CD
  - ▶ Play an iPod
  - ▶ Play from a USB memory device
- 6 Enjoying music using PC or Mac


# Install batteries in the remote control unit




# 2 Connect the CD player to the amplifier



# Plug the power cord into a power outlet




# Turn the CD player's power on




# 5 Begin music playback


▶ Play a CD or Super Audio CD




Press  $\triangle$  to open the disc tray. Place CD in the disc tray. Press ▶. Playback starts.

## Play an iPod





Connect the iPod to the USB port.




Press INPUT to select the playback media mode to "USB".




- •You can also select the playback media mode by pressing DISC/INPUT on the unit.
- Operate iPod itself directly while seeing the iPod screen to play back music.


Playback starts.

### ▶ Play from a USB memory device





Connect the USB memory device to the USB port.



Press INPUT to select the playback media mode to "USB".

Playback starts automatically.




•You can also select the playback media mode by pressing DISC/INPUT on the unit.

## 6 Enjoying music using PC or Mac

### □ Connect to PC or Mac

- Download the driver for this unit from the Marantz web site and install it on your PC.
- Drivers do not need to be installed for Mac OS.
- Download the driver software from the Marantz website.
- •Operation will not occur correctly if connected to the computer before the dedicated driver has been installed.
- For instructions on operation, refer to the owner's manual.



### ☐ Listen to PC or Mac Audio

1 Press INPUT to change the input source to "USB-DAC".



Play back a music file with music playback software such as foobar 2000, Audirvana Plus and JRiver Media Center.



The sampling frequency of the music file is displayed.




 Please refer to the Owner's manual about the required specifications of suiting Computer.

## **Owner's Manual**

The included CD-ROM contains an Adobe PDF version of the full owner's manual for the CD player.

Please reference this manual for more details about the setup and operation of the CD player and it's features.







• You can also download the owner's manual from the Marantz website.

www.marantz.com





Product Name: Super Audio CD Player

Model Number: SA8005

#### www.marantz.com

You can find your nearest authorized distributor or dealer on our website.

marantz\* is a registered trademark.